

New functions and addendum

- This document contains descriptions of how to set the new functions and their restrictions. It is recommended to read them while referring to the Operating Instructions provided with this product together.
- Depending on the model used, the screens shown in the explanations may differ to the actual camera screens.
- The model number is abbreviated in some descriptions in this manual.
- This document is for the following models.
WV-X6533LN, WV-S6532LN

Due to software upgrade, the following functions have been added and changed to this product.

• **Firmware Ver.4.20**

No.	Functions	Item (Page)	Page
1	Addition of "Pan/Tilt Operability" setting to the "Cam. Function"	Cam. Function (Image/Audio)	2

• **Firmware Ver.4.30**

No.	Functions	Item (Page)	Page
2	Change of [Internet mode] default setting	Image(Image/Audio)	3
3	Enhanced the access restriction function of SNMP v1/v2	Advanced (Network)	4
4	Added "SNMP transmission upon alarm detection" to "Camera action on alarm"	Camera action on alarm (Alarm)	5
5	Added "SNMP trap setting" to "SNMP"	Advanced (Network)	6

1. Addition of “Pan/Tilt Operability” setting to the “Cam. Function”

(Operating Instructions Configure the settings relating to images and audio [Image/Audio]
- Configure the settings relating to the camera operations [Cam. Function])

Add the "Pan/Tilt Operability" selection function to the camera operating setting.

Image	Cam. Function	Image/Position	Audio
Home position	<input type="text" value="Off"/>		
Self return	<input type="text" value="Off"/>		
Self return time	<input type="text" value="1min"/>		
Upside-down	<input type="radio"/> On	<input type="radio"/> Off	
HD Extra optical zoom	<input type="radio"/> On	<input type="radio"/> Off	
Digital zoom	<input checked="" type="radio"/> On	<input type="radio"/> Off	
Number of Privacy zone	<input type="radio"/> 8	<input type="radio"/> 32	
Privacy zone	<input type="text" value="Filling"/>		
Camera position display	<input type="text" value="Pan-Tilt degree/Zoom ratio display"/>		
Operation mode display	<input checked="" type="radio"/> On	<input type="radio"/> Off	
Tilt Angle	<input type="text" value="-30 °"/>		
Focus distance	<input type="radio"/> Unlimited	<input checked="" type="radio"/> Limited	
Pan/Tilt Operability	<input type="text" value="Profile1(Normal)"/>		

[Pan/Tilt Operability]

The operability when pan / tilt is operated using the joystick can be selected.

Profile1(Normal) : Select this setting for Panasonic systems starting with "WV-" or "WJ-".

Profile2 : Operability in the low speed range can be improved.

Select this setting when the camera movement is not good in the low speed range.

Profile3 : Operability in the middle and high speed range can be improved.

Select this setting when the camera speed is too high in middle and high speed range.

Default : Profile1(Normal)

2. Change of [Internet mode] default setting

(Operating Instructions Configure the settings relating to images and audio

[Image/Audio] Configure the settings relating to Stream [Image])

Change of [Internet mode] default setting.

Stream(1)	
Stream transmission	<input type="radio"/> On <input checked="" type="radio"/> Off
Stream encoding format	<input type="radio"/> H.265 <input checked="" type="radio"/> H.264
Internet mode	<input type="radio"/> On <input checked="" type="radio"/> Off

[Internet mode]

Select “On” when transmitting H.265 (or H.264) images via the Internet. It is possible to transmit stream without changing the broadband router settings configured for JPEG image transmission.

- **On:** H.265 (or H.264) images and audio will be transmitted using the HTTP port. Refer to [HTTP port] for further information about the HTTP port number settings.
- **Off:** H.265 (or H.264) images and audio will be transmitted using the UDP port.
- **Default:** On

Note

- When “On” is selected, only “Unicast port (AUTO)” will be available for “Transmission type”.
- When “On” is selected, it may take time to start displaying stream images.
- When “On” is selected, stream images may not be displayed depending on the number of the concurrent access user and audio data availability, etc.
- When “On” is selected, only IPv4 access is available.

3. Enhanced the access restriction function of SNMP v1/v2

(Operating Instructions “Configuring the network settings” [Network]

- “Configure advanced network settings” [Advanced]
- “Configure the settings relating to SNMP”)

The address range setting of the SNMP manager that receives requests from the camera is newly added.

The screenshot shows a web interface with two tabs: 'Network' and 'Advanced'. The 'Advanced' tab is selected. Below the tabs is a navigation bar with links: SMTP(E-mail), FTP, NTP, UPnP, HTTPS, DDNS, SNMP (highlighted in yellow), and QoS. The main content area is titled 'SNMP agent setting'. It contains a table with the following fields:

SNMP agent setting		
SNMP version	SNMPv1/v2	
SNMPv1/v2	Community	
	Manager address	
SNMPv3	User name (1 to 32 characters)	
	Authentication	<input type="radio"/> MD5 <input type="radio"/> SHA1
	Encryption method	<input type="radio"/> DES <input type="radio"/> AES
	Password (8 to 16 characters)	

- **[Manager address]**

Enter the IP address of the SNMP manager from which requests are to be permitted when the SNMP version is v1 or v2. When left blank, requests from all IP addresses will be permitted.

Note

- When “IP address/subnet mask” is entered, it is possible to restrict IP address of SNMP manager from which request is permitted by subnet.

For example, when “192.168.0.1/24” is entered, all requests from the SMNP managers in the range from “192.168.0.1” to “192.168.0.254” will be permitted.

Available number of characters: 0 - 128 characters

Available characters: Alphanumeric characters, the colon (:), the period (.) and the slash (/).

Default: None (blank)

4. Added “SNMP transmission upon alarm detection” to “Camera action on alarm on alarm”

(Operating Instructions “Configure the alarm settings” [Alarm] - “Configure the settings relating to the camera action on alarm occurrence”)

“SNMP transmission upon alarm detection” is newly added to the settings relating to the camera action on alarm.

Click “To SNMP setting” to display the setup menu that can configure the settings relating to SNMP transmission when an alarm occurs. The setup menu will be displayed in a newly opened window.

(→ 5. Added “SNMP trap setting” to “SNMP”)

Camera action on alarm	
Terminal alarm 1	Off
Terminal alarm 2	Off
Terminal alarm 3	Off
VMD alarm	Off
Audio detection alarm	Off
Command alarm	Off
	Preset per sender >>
Image compression rate upon alarm detection	Image compression rate upon alarm detection setup >>
Alarm E-mail notification	E-mail server >>
Alarm image FTP transmission	FTP setup >>
Alarm image recording(SD memory card)	SD memory card setup >>
Panasonic alarm protocol	Panasonic alarm protocol notification >>
HTTP alarm notification	HTTP alarm notification setup >>
SNMP transmission upon alarm detection	To SNMP setting

5. Added “SNMP trap setting” to “SNMP”

(Operating Instructions “Configuring the network settings” [Network] - “Configure advanced network settings” [Advanced] - “Configure the settings relating to SNMP”)

“SNMP trap setting” is newly added to the settings relating to SNMP.
Configure settings relating to SNMP trap when an alarm occurs.

SNMP trap setting		<input checked="" type="radio"/> On	<input type="radio"/> Off
Destination of Trap	Address	<input type="text"/>	
	Port number	<input type="text" value="162"/>	(1-65535)
SNMPv2c	Community	<input type="text"/>	
Trap setting		Enable/Disable	Trap string
SNMP Generic trap	<input type="checkbox"/> coldStart	<input type="text" value="cold start"/>	
	<input type="checkbox"/> linkUp	<input type="text" value="linkup"/>	
	<input type="checkbox"/> authenticationFailure	<input type="text" value="auth error"/>	
Alarm	<input type="checkbox"/> Terminal 1	<input type="text" value="terminal alarm 1"/>	
	<input type="checkbox"/> Terminal 2	<input type="text" value="terminal alarm 2"/>	
	<input type="checkbox"/> Terminal 3	<input type="text" value="terminal alarm 3"/>	
	<input type="checkbox"/> VMD	<input type="text" value="VMD alarm"/>	
	<input type="checkbox"/> Auto track	<input type="text" value="auto track alarm"/>	
	<input type="checkbox"/> Audio detection	<input type="text" value="audio"/>	
	<input type="checkbox"/> Command alarm	<input type="text" value="cmd"/>	
SD memory card	<input type="checkbox"/> Diag.	<input type="text" value="sd alarm"/>	
Ext. software	<input type="checkbox"/> Alarm	<input type="text" value="alarm"/>	

- **[SNMP trap setting]**

Set On/Off of the SNMP trap.

Default: Off

- **[Destination of Trap] - [Address]**

Enter the destination address of the SNMP trap.

Available number of characters: 0 - 128 characters

Available characters: Alphanumeric characters, the colon (:) and the period (.).

Default: None (blank)

- **[Destination of Trap] - [Port number]**

Enter the port number of the destination address of the SNMP trap.

Available port number: 1 - 65535

Default: 162

The following port numbers are unavailable since they are already in use.

20, 21, 23, 25, 42, 53, 67, 68, 69, 80, 110, 123, 161, 443, 554, 995, 10669, 10670, 59000 - 61000

- **[SNMPv2c] - [Community]**

Enter the community name of the destination address of the SNMP trap.

Available number of characters: 0 - 32 characters

Unavailable characters: 2-byte characters

Default: None (blank)

IMPORTANT

- When using the SNMP trap function, it is necessary to enter the community name. When no community name is entered, the SNMP trap function will not work.

- **[SNMP Generic trap] - [coldStart] - [Enable/Disable]**

When the check box is checked, a trap (SNMPv2-MIB::coldStart) will be sent.

Default: Not checked (Disable)

- **[SNMP Generic trap] - [coldStart] - [Trap string]**

When a camera startup trap is to be extended and sent, set the string of characters of the extended trap.

Available number of characters: 0 - 32 characters

Unavailable characters: 2-byte characters

Default: cold start

- **[SNMP Generic trap] - [linkUP] - [Enable/Disable]**

When the check box is checked, a trap (SNMPv2-MIB::linkup) will be sent at the time when the camera is linked up.

Default: Not checked (Disable)

- **[SNMP Generic trap] - [linkUP] - [Trap string]**

When a camera linkup trap is to be extended and sent, set the string of characters of the extended trap.

Available number of characters: 0 - 32 characters

Unavailable characters: 2-byte characters

Default: linkup

- **[SNMP Generic trap] - [authenticationFailure] - [Enable/Disable]**

When the check box is checked, a trap (SNMPv2-MIB::coldStart) will be sent at the time when an SNMP authentication error occurs.

Default: Not checked (Disable)

- **[SNMP Generic trap] - [authenticationFailure] - [Trap string]**

When a SNMP authentication error occurrence trap is to be extended and sent, set the string of characters.

Available number of characters: 0 - 32 characters

Unavailable characters: 2-byte characters

Default: auth error

- **[Alarm] - [Terminal 1] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time when an alarm occurs in terminal 1.
Default: Not checked (Disable)
- **[Alarm] - [Terminal 1] - [Trap string]**
Set the string of characters to be used for the trap of [Terminal 1].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: terminal alarm 1
- **[Alarm] - [Terminal 2] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time when an alarm occurs in terminal 2.
Default: Not checked (Disable)
- **[Alarm] - [Terminal 2] - [Trap string]**
Set the string of characters to be used for the trap of [Terminal 2].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: terminal alarm 2
- **[Alarm] - [Terminal 3] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time when an alarm occurs in terminal 3.
Default: Not checked (Disable)
- **[Alarm] - [Terminal 3] - [Trap string]**
Set the string of characters to be used for the trap of [Terminal 3].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: terminal alarm 3
- **[Alarm] - [VMD] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time when a video motion detection is activated.
Default: Not checked (Disable)
- **[Alarm] - [VMD] - [Trap string]**
Set the string of characters to be used for the trap of [VMD].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: VMD alarm
- **[Alarm] - [Auto track] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time when an auto track is activated.
Default: Not checked (Disable)
- **[Alarm] - [Auto track] - [Trap string]**
Set the string of characters to be used for the trap of [Auto track].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: auto track alarm
- **[Alarm] - [Audio detection] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time of an audio detection is activated.
Default: Not checked (Disable)

- **[Alarm] - [Audio detection] - [Trap string]**
Set the string of characters to be used for the trap of [Audio detection].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: audio
- **[Alarm] - [Command alarm] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time when a command alarm occurs.
Default: Not checked (Disable)
- **[Alarm] - [Command alarm] - [Trap string]**
Set the string of characters to be used for the trap of [Command alarm].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: cmd
- **[SD memory card] - [Diag.] - [Enable/Disable]**
When the check box is checked, a trap will be sent in the following cases.
 - When a notification of the remaining capacity of SD memory card has been provided
 - When the SD memory card has become full
 - When the SD memory card cannot be recognized**Default:** Not checked (Disable)
- **[SD memory card] - [Diag.] - [Trap string]**
Set the string of characters to be used for the trap of [Diag.].
Available number of characters: 0 - 32 characters
Unavailable characters: 2-byte characters
Default: sd alarm
- **[Ext. Software] - [Alarm] - [Enable/Disable]**
When the check box is checked, a trap will be sent at the time when an alarm occurs in the extension software.
Note
 - This setting will not be displayed if the extension software is not installed.**Default:** Not checked (Disable)
- **[Ext. Software] - [Alarm] - [Trap string]**
Set the string of characters to be used for the trap of [Ext. software].
Note
 - This setting will not be displayed if the extension software is not installed.**Available number of characters:** 0 - 32 characters
Unavailable characters: 2-byte characters
Default: alarm