

Panasonic and Sanyo Lamp Table

| Panasonic Model Name | Sanyo Model Name | Sanyo Parts code | Description : Compatible Main Unit | Produced In | Category |
|----------------------|------------------|------------------|---|-------------|--------------|
| ET-LAC100 | POA-LMP143 | 6103513744 | PLC-DWL2500, PLC-DXL2500 | China | Portable |
| ET-LAE12 | POA-LMP146 | 6103515939 | PLC-HF10000 | Japan | System |
| ET-LAE16 | POA-LMP147 | 6103509051 | PLC-HF15000 | Japan | System |
| ET-LAT100 | POA-LMP141 | 6103490847 | PLC-WL2500A, PLC-WL2503A | China | Portable |
| ET-LAV100 | POA-LMP148 | 6103527949 | PLC-XU4000 | China | Portable |
| ET-LAV100 | POA-LMP150 | 6103576336 | PLC-XU4001, PLC-WU3001 | China | Portable |
| ET-SLMP14 | PLC-LMP14 | 6102658828 | PLC-5600E, PLC-5605E, PLC-8800E, PLC-8805E, PLC-8810E, PLC-8815E, PLC-XR70E | Japan | Portable |
| ET-SLMP15M | POA-LMP15M | 6102907698 | PLC-EF10, PLC-9000E, PLC-9000EA, PLC-9005EA, PLC-9005E, PLC-9005EL | Japan | System |
| ET-SLMP18 | POA-LMP18J | 6102795417 | PLC-XP10EA | Japan | Installation |
| ET-SLMP21 | POA-LMP21J | 6102806939 | PLC-XU20E | Japan | Portable |
| ET-SLMP24 | POA-LMP24 | 6102822755 | PLC-XP21 | Japan | Installation |
| ET-SLMP26A | POA-LMP26A | 6102983135 | PLC-EF10EA, PLC-EF10EAL, PLC-XF10E, PLC-XF12E, PLC-EF12E | Japan | System |
| ET-SLMP27 | POA-LMP27 | 6102875379 | PLC-SU07E, PLC-SU10E, PLC-SU15E, PLC-XU10E | Japan | Portable |
| ET-SLMP28 | POA-LMP28 | 6102854824 | PLC-XP30, PLC-XP30E, PLV-60 | Japan | Installation |
| ET-SLMP29 | POA-LMP29 | 6102844627 | PLC-XF20E | Japan | System |
| ET-SLMP35 | POA-LMP35 | 6102932751 | PLC-SU30, PLC-SU31, PLC-SU32, PLC-XU30, PLC-XU31, PLC-XU32, PLC-XU33, PLC-XU35, PLC-XU37, PLC-XU38 | Japan | Portable |
| ET-SLMP36 | POA-LMP36 | 6102938210 | PLC-SW20, PLC-XW20 | Japan | Portable |
| ET-SLMP37 | POA-LMP37 | 6102955712 | PLC-SW20, PLC-SW20A | Japan | Portable |
| ET-SLMP39 | POA-LMP39 | 6102924848 | PLC-EF30, PLC-XF30, PLC-EF31, PLC-XF31 | Japan | System |
| ET-SLMP42 | POA-LMP42 | 6102924831 | PLC-UF10, PLC-XF30, PLC-EF31, PLC-XF31 | Japan | System |
| ET-SLMP47 | POA-LMP47 | 6102973891 | PLC-XP46 | Japan | Installation |
| ET-SLMP48 | POA-LMP48 | 6103017167 | PLC-XT15 | Japan | Installation |
| ET-SLMP49 | POA-LMP49 | 6103000862 | PLC-UF15, PLC-XF42, PLC-XF45 | Japan | System |
| ET-SLMP51 | POA-LMP51 | 6103007267 | PLC-XW20A, PLC-XW20AR | Japan | Portable |
| ET-SLMP52 | POA-LMP52 | 6103016047 | PLC-XF35 | Japan | System |
| ET-SLMP53 | POA-LMP53 | 6103035826 | PLC-XU40 | Japan | Portable |
| ET-SLMP54 | POA-LMP54 | 6103025933 | PLV-Z1, PLV-Z1B | Japan | Portable |
| ET-SLMP55 | POA-LMP55 | 6103092706 | PLC-XL20, PLC-XU47, PLC-XU48, PLC-XU50, PLC-XU51, PLC-XU55, PLC-XU58 | Japan | Portable |
| ET-SLMP56 | POA-LMP56 | 6103058801 | PLC-XU46 | Japan | Portable |
| ET-SLMP57 | POA-LMP57 | 6103083117 | PLC-SW30 | Japan | Portable |
| ET-SLMP59 | POA-LMP59 | 6103055602 | PLC-XT10, PLC-XT10A, PLC-XT11, PLC-XT15, PLC-XT15A, PLC-XT16 | Japan | Installation |
| ET-SLMP65 | POA-LMP65 | 6103077925 | PLC-SL20, PLC-SU50, PLC-XU50S, PLC-SU51, PLC-XL20, PLC-XU50, PLC-XU55, PLC-XU56 | Japan | Portable |
| ET-SLMP66 | POA-LMP66 | 6103110486 | PLE-SE20, SE20A | Japan | Portable |
| ET-SLMP67 | POA-LMP67 | 6103065977 | PLC-XP55 | Japan | Installation |
| ET-SLMP68 | POA-LMP68 | 6103081786 | PLC-XC10 | Japan | Portable |
| ET-SLMP69 | POA-LMP69 | 6103097589 | PLV-Z2 | Japan | Home |
| ET-SLMP72 | POA-LMP72 | 6103051130 | PLC-HD10 | Japan | System |
| ET-SLMP73 | POA-LMP73 | 6103093802 | PLV-WF10, PLC-WF10, PLV-WF10-R | Japan | Installation |
| ET-SLMP79 | POA-LMP79 | 6103155647 | PLC-XU41 | Japan | Portable |
| ET-SLMP80 | POA-LMP80 | 6103157689 | PLC-XF60 | Japan | System |
| ET-SLMP81 | POA-LMP81 | 6103149127 | PLC-XP56, PLC-XP51 | Japan | Installation |
| ET-SLMP86 | POA-LMP86 | 6103175355 | PLV-Z3 | Japan | Home |
| ET-SLMP87 | POA-LMP87 | 6103184821 | PLC-XP41L | Japan | Installation |
| ET-SLMP91 | POA-LMP91 | 6103213804 | PLC-SW35 | Japan | Portable |
| ET-SLMP93 | POA-LMP93 | 6103230719 | PLC-XU70 | Japan | Portable |
| ET-SLMP94 | POA-LMP94 | 6103235998 | PLV-Z4, PLV-Z5, PLV-Z60 | Japan | Home |
| ET-SLMP95 | POA-LMP95 | 6103235394 | PLV-HD150 | Japan | System |
| ET-SLMP98 | POA-LMP98 | 6103252957 | PLV-80 | Japan | Installation |
| ET-SLMP99 | POA-LMP99 | 6103252940 | PLC-XP40L, PLC-XP45L, PLV-70L, PLV-75L | Japan | Installation |
| ET-SLMP100 | POA-LMP100 | 6103274928 | PLC-XF46, PLV-HD2000E | Japan | System |
| ET-SLMP101 | POA-LMP101 | 6103287362 | PLC-XP57 | Japan | Installation |
| ET-SLMP102 | POA-LMP102 | 6103286549 | PLC-XE31 | Japan | Portable |
| ET-SLMP103 | POA-LMP103 | 6103316345 | PLC-XU100, PLC-XU110 | Japan | Portable |
| ET-SLMP104 | POA-LMP104 | 6103370262 | PLC-XF70 | Japan | System |
| ET-SLMP105 | POA-LMP105 | 6103307329 | PLC-XT20, PLC-XT25 | Japan | Installation |
| ET-SLMP106 | POA-LMP106 | 6103323855 | PLC-WXE45, PLC-WXE46, PLC-WXE46A, PLC-WXL46, PLC-WXL46A, PLC-XE45, PLC-XL45, PLC-XU74 | China | Portable |
| ET-SLMP107 | POA-LMP107 | 6103304564 | PLC-XW50, PLC-XW55 | Japan | Portable |
| ET-SLMP108 | POA-LMP108 | 6103342788 | PLC-XP100L | Japan | Installation |
| ET-SLMP109 | POA-LMP109 | 6103346267 | PLC-XF47 | Japan | System |
| ET-SLMP111 | POA-LMP111 | 6103339740 | PLC-WXU30, PLC-WXU30A, PLC-WXU3ST, PLC-WXU700A, PLC-XU101, PLC-XU105, PLC-XU106, PLC-XU111, PLC-XU115, PLC-XU116, PLC-WXU3800 | China | Portable |
| ET-SLMP113 | POA-LMP113 | 6103360362 | PLC-WXU10 | Japan | Portable |
| ET-SLMP115 | POA-LMP115 | 6103349565 | PLC-XU75, PLC-XU78, PLC-XU88 | China | Portable |
| ET-SLMP116 | POA-LMP116 | 6103358093 | PLC-ET30L, PLC-XT35, PLC-XT35L | Japan | Installation |
| ET-SLMP117 | POA-LMP117 | 6103358406 | PDG-DXT10L | Japan | Installation |
| ET-SLMP121 | POA-LMP121 | 6103379937 | PLC-XE50, PLC-XL50, PLC-XL51, PLC-XL51A | Japan | Short throw |
| ET-SLMP122 | POA-LMP122 | 6103400341 | PLC-XW57 | China | Portable |
| ET-SLMP123 | POA-LMP123 | 6103391700 | PLC-XW60 | China | Portable |
| ET-SLMP124 | POA-LMP124 | 6103411941 | PLC-XP200L | Japan | Installation |
| ET-SLMP125 | POA-LMP125 | 6103422626 | PLC-WTC500L, PLC-XTC50AL, PLC-XC55A, PLC-XC56 | Japan | Installation |
| ET-SLMP127 | POA-LMP127 | 6103398600 | PLC-XC56 | China | Portable |
| ET-SLMP128 | POA-LMP128 | 6103419497 | PLC-XF71, PLC-XF1000 | Japan | System |
| ET-SLMP129 | POA-LMP129 | 6103417493 | PLC-XW65 | China | Portable |
| ET-SLMP130 | POA-LMP130 | 6103435336 | PDG-DET100L, PDG-DHT100L | Japan | System |
| ET-SLMP131 | POA-LMP131 | 6103432069 | PLC-XU301A, XU305A, XU350A, XU355A, WXU300 | China | Portable |
| ET-SLMP132 | POA-LMP132 | 6103452456 | PLC-XW200, PLC-XW250 | China | Portable |
| ET-SLMP135 | POA-LMP135 | 6103445120 | PLV-Z2000, PLV-Z3000, PLV-Z4000, PLV-Z700, PLV-Z800 | Japan | Home |
| ET-SLMP136 | POA-LMP136 | 6103469607 | PLC-XM150L, PLC-XW5500L, PLC-ZM5000L | China | Installation |
| ET-SLMP137 | POA-LMP137 | 6103475158 | PLC-XM100L, PLC-XW4500L | China | Installation |
| ET-SLMP139 | POA-LMP139 | 6103478791 | PLCXL50A | Japan | Short throw |
| ET-SLMP142 | POA-LMP142 | 6103497518 | PLC-XD2200, PLC-XD2600, PLC-XK2200, PLC-XK2600, PLC-XK3010, PLC-XE34, PLC-WK2500 | China | Portable |
| ET-SLMP145 | POA-LMP145 | 6103506814 | PDG-DHT8000L | Japan | System |
| ET-SLMP149 | POA-LMP149 | 6103570464 | PLC-HP7000L | Japan | Installation |

Panasonic and Sanyo Option Table

| Panasonic Model Name | Sanyo Model Name | Description : Compatible Main Unit | Produced In | Category |
|----------------------|------------------|---|-------------|----------------------------|
| ET-SS04 | LNS-S04 | PLC-HF15000L,PLC-HF10000L | Japan | Lens |
| ET-SM02 | LNS-M02 | PLC-HF15000L,PLC-HF10000L,PLC-XF47A,PLC-XF47 | Japan | Lens |
| ET-SW05 | LNS-W05 | PLV-WF20 | Japan | Lens |
| ET-SW07 | LNS-W07 | PLV-WF20 | Japan | Lens |
| ET-SW33 | LNS-W33 | PLC-HP7000L | Japan | Lens |
| ET-SW34 | LNS-W34 | PLC-HP7000L | Japan | Lens |
| ET-SS32 | LNS-S32 | PLC-HP7000L | Japan | Lens |
| ET-ST32 | LNS-T32 | PLC-HP7000L,PLC-XP200L,PLC-XP100L | Japan | Lens |
| ET-ST33 | LNS-T33 | PLC-HP7000L,PLC-XP200L,PLC-XP100L | Japan | Lens |
| ET-ST34 | LNS-T34 | PLC-HP7000L | Japan | Lens |
| ET-SW32E | LNS-W32E | PLC-XP200L,PLC-XP100L | Japan | Lens |
| ET-SW31A | LNS-W31A | PLC-XP200L,PLC-XP100L | Japan | Lens |
| ET-SS31 | LNS-S31 | PLC-XP200L,PLC-XP100L | Japan | Lens |
| ET-ST31A | LNS-T31A | PLC-XP200L,PLC-XP100L | Japan | Lens |
| ET-SS20 | LNS-S20 | PLCZM5000L.PLC-WM5500/4500L,PLC-XM150/100L | Japan | Lens |
| ET-SW52 | LNS-W52 | PDG-DHT8000L,PDG-DHT100L,PDG-DET100L | Japan | Lens |
| ET-SW53 | LNS-W53 | PDG-DHT8000L,PDG-DHT100L,PDG-DET100L | Japan | Lens |
| ET-SS51 | LNS-S51 | PDG-DHT8000L,PDG-DHT100L,PDG-DET100L | Japan | Lens |
| ET-ST50 | LNS-T50 | PDG-DHT8000L,PDG-DHT100L,PDG-DET100L | Japan | Lens |
| ET-ST51 | LNS-T51 | PDG-DHT8000L,PDG-DHT100L,PDG-DET100L | Japan | Lens |
| ET-SSR160 | POA-SR-160 | PLC-HF15000L (For Sanyo Models Only) | Japan | Smoke Cut Filter Cartridge |
| ET-SFYL063 | POA-FIL-063 | PLC-XC56,PLC-XC55,PLC-XC50 (For Sanyo Models Only) | Japan | Filter |
| ET-SFYL080 | POA-FIL-080 | PLC-ZM5000L.PLC-WM5500L,PLC-XM150/100L (For Sanyo Models Only) | Japan | Filter |
| ET-SFYL081 | POA-FIL-081 | PLC-WM4500L (For Sanyo Models Only) | Japan | Filter |
| ET-SFYL090 | POA-FIL-090 | PDG-DHT8000L (For Sanyo Models Only) | Japan | Filter |
| ET-SFYL100 | POA-FIL-100 | PLC-XTC50I,PLC-WTC500L (For Sanyo Models Only) | Japan | Filter |
| ET-SFYL131 | POA-FIL-131 | PLC-XP100L,PLC-XP200L.PDG-DHT100L,PDG-DET100L (For Sanyo Models Only) | Japan | Filter |
| ET-SFYL180 | POA-FIL-180 | PLC-WF20,PLC-XF71 (For Sanyo Models Only) | Japan | Filter |
| ET-SA22SDYDL | POA-AMD22SDIDL | PLC-HF15000L,PLC-HF10000L | Japan | Interface board |
| ET-SA23ADYA | POA-AMD23ADI-A | PLC-HF15000L,PLC-HF10000L,PLC-XF47A,PDG-DHT8000L | Japan | Interface board |
| ET-SA25VD3A | POA-AMD25VD3-A | PLC-HF15000L,PLC-HF10000L,PLC-XF47A,PDG-DHT8000L | Japan | Interface board |
| ET-SA27NETA | POA-AMD27NET-A | PLC-XF47A | Japan | Interface board |
| ET-S16VD1 | POA-MD16VD1 | PLV-WF20,PLC-XF47,PLC-XF1000,PLC-XF71,PDG-DET100L | Japan | Interface board |
| ET-S17SDYD | POA-MD17SDID | PLV-WF20,PLC-XF47,PLC-XF1000,PLC-XF71,PDG-DET100L | Japan | Interface board |
| ET-S18DVY | POA-MD18DVI | PLV-WF20,PLC-XF47,PLC-XF1000,PLC-XF71,PDG-DET100L | Japan | Interface board |
| ET-S23ADY | POA-MD23ADI | PLV-WF20,PLC-XF47,PLC-XF1000,PLC-XF71,PDG-DET100L | Japan | Interface board |
| ET-SCACMPVGA | POA-CA-COMPVGA | D-sub15-component Cable | Japan | Others |
| ET-SLNA01 | POA-LNA-01 | Lens attachment for LNS-W01, 03, S02, S03 and T01 | Japan | Others |
| ET-SLNA02 | POA-LNA-02 | Lens attachment for LNS-W02, W02KS, M01 and S01 | Japan | Others |
| ET-SLNA03 | POA-LNA-03 | Lens attachment for LNS-W31A,T31A and W32 | Japan | Others |